

Sanmei Invention Servo  
*Sí servo 3*

---

# Instruction Manual

Serial communication part

# Table of Contents

|         |  |    |
|---------|--|----|
| 1.      | Before use .....   | 1  |
| 2.      | Communication specifications .....   | 2  |
| 2-1.    | Communication specifications .....   | 2  |
| 3.      | Communication protocol .....   | 3  |
| 3-1.    | Communication frame structure .....  | 3  |
| 3-2.    | Data string format .....   | 3  |
| 3-3.    | Single axis command communication .....  | 4  |
| 3-4.    | All axes command communication .....   | 4  |
| 3-5.    | Group command communication .....  | 4  |
| 3-6.    | Overall command communication .....  | 5  |
| 3-7.    | Wildcard command communication .....   | 5  |
| 3-8.    | Command input method select .....  | 6  |
| 3-9.    | Communication error reply .....  | 7  |
| 4.      | Communication commands list .....  | 8  |
| 5.      | Communication commands details .....   | 11 |
| 5-1.    | Parameters/Point-Table setting commands .....  | 11 |
| 5-1-1.  | [PR] [PRMR] Parameter read .....   | 11 |
| 5-1-2.  | [PW] [PRMW] Parameter write .....  | 12 |
| 5-1-3.  | [PTR] [TR] Point-Table read .....  | 13 |
| 5-1-4.  | [PTW] [TW] Point-Table write .....   | 14 |
| 5-1-5.  | [PTRS] Point-Table item read .....   | 15 |
| 5-1-6.  | [PTWS] Point-Table item write .....  | 15 |
| 5-1-7.  | [FLASH] EEPROM write .....   | 16 |
| 5-2.    | Basic operation commands .....   | 17 |
| 5-2-1.  | [SVON] [SVOFF] Servo ON/OFF .....  | 17 |
| 5-2-2.  | [EMCON] [EMCOFF] Emergency stop ON/OFF .....   | 18 |
| 5-2-3.  | [STRON] [STROFF] [STRP] Point-Table start ON/OFF .....   | 19 |
| 5-2-4.  | [STROND] [STRPD] Point-Table specified start .....   | 20 |
| 5-2-5.  | [ZSTRON] [ZSTROFF] [ZSTRP] Homing start ON/OFF .....   | 21 |
| 5-2-6.  | [STOP] Stop operation .....  | 22 |
| 5-2-7.  | [DECON] [DECOFF] Home deceleration LS ON/OFF .....   | 22 |
| 5-2-8.  | [HOLDON] [HOLDOFF] Pause (HOLD) ON/OFF .....   | 23 |
| 5-2-9.  | [SBKON] [SBKOFF] Single block ON/OFF .....   | 23 |
| 5-2-10. | [EXINON] [EXINOFF] [EXIN1ON] [EXIN1OFF] [EXIN2ON] [EXIN2OFF] [EXIN3ON] [EXIN3OFF]<br>Input branch ON/OFF ..... | 24 |
| 5-2-11. | [PJOG] [NJOG] [JOGOFF] JOG operation .....   | 25 |
| 5-2-12. | [TDIN] Teaching .....  | 26 |
| 5-2-13. | [ARST] Alarm reset .....   | 26 |
| 5-2-14. | [TRST] Torque peak reset .....   | 26 |
| 5-2-15. | [PNT] Point specify .....  | 27 |
| 5-2-16. | [HCL] Alarm history clear .....  | 27 |
| 5-2-17. | [RESET] CPU reset .....  | 28 |
| 5-2-18. | [ZSET] Machine home rewrite .....  | 28 |
| 5-2-19. | [ESET] Error counter set .....   | 28 |

|         |  |    |
|---------|--|----|
| 5-2-20. | [RSELON] [RSELOFF] Resolution selection .....  | 29 |
| 5-2-21. | [TSELON] [TSELOFF] [TSEL0ON] [TSEL1ON] [TSEL2ON] [TSEL3ON] [TSEL4ON] Torque select .....                           | 30 |
| 5-2-22. | [MFINON] [MFINOFF] M complete input ON/OFF .....   | 31 |
| 5-2-23. | [STEPON] [STEP0FF] [STEP0ON] [STEP1ON] [STEP2ON] [STEP3ON] Step operation .....                                    | 31 |
| 5-2-24. | [STEP0P] [STEP0N] [STEP1P] [STEP1N] [STEP2P] [STEP2N] [STEP3P] [STEP3N] Step operation (direction specified) ..... | 32 |
| 5-2-25. | [SLREQON] [SLREQOFF] Transition to / Cancel sensor input standby state .....                                       | 32 |
| 5-2-26. | [DPS] Direct positioning start .....   | 33 |
| 5-3.    | Monitor commands .....   | 34 |
| 5-3-1.  | [MON] Value monitor .....  | 34 |
| 5-3-2.  | [ALM] Alarm information .....  | 36 |
| 5-3-3.  | [IO2] I/O monitor 2 .....  | 37 |
| 5-3-4.  | [ALMP] Alarm read .....  | 38 |
| 5-3-5.  | [ALHP] Alarm history read .....  | 38 |
| 5-3-6.  | [DIAG] Monitor·Read diagnostic information .....   | 39 |
| 6.      | Appendix .....   | 40 |
| 6-1.    | Old model (Si servo2) parameters correspondence table .....  | 40 |

## 1. Before use

- "Si servo3 Instruction Manual (Serial communication part) SH2882D073" describes the serial communication functions of Si servo3. In addition to this manual, carefully read the related editions "Si servo3 Instruction Manual (Main part) SH2882D071", "Si servo3 Instruction Manual (Point-Table part) SH2882D072" and the booklet attached to the motor to understand the correct usage.
- In particular, be sure to understand and remember the contents of "Safety Precautions" described in "Si servo3 Instruction Manual (Main part) SH2882D071". Be careful not to mishandle the equipment in any case. Improper use may lead to serious accidents including death.
- After reading this instruction manual, the related editions, and the booklet attached to the motor, keep them in a place where you can access and read them whenever needed.


### Servo driver models to which the contents of this manual apply

|                  |                            |
|------------------|----------------------------|
| <b>Si servo3</b> | <b>Si-02DT<br/>Si-05DT</b> |
|------------------|----------------------------|

## 2. Communication specifications

Si servo3 uses RS485 (2-wire type) with multidrop link to control multiple axes.

### 2 – 1. Communication specifications



|                          |  |
|--------------------------|--|
| Compliant standard       | RS485                                  |
| Communication method     | asynchronous                           |
|                          | characters                             |
|                          | half-duplex                            |
| Baud rate (*1)           | 9600, 19200, 38400<br>57600, 115200bps |
| Start bit                | 1bit                                   |
| Data format              | 8bit<br>ASCII code<br>HEX              |
| Parity                   | 1 bit (even)                           |
| Stop bit                 | 1bit                                   |
| Checksum                 | none                                   |
| Maximum cable length     | 20m                                    |
| Configurable axis number | 15 selections (00~0E)                  |

\*1) Baud rate is switched with the parameter of Si servo driver.


## 3. Communication protocol

### 3 – 1. Communication frame structure

A single communication frame is the transmission from the start code STX (02h) to the end code ETX (03h) or EOT (04h).

For the end code, both ETX and EOT can be used for communication with the servo driver.

The end code for a servo driver reply to the host controller can be selected with the parameter N0419 "Communication format select". The axis number of the servo driver is set by the parameter N0020 "Axis number".



Communication method is half-duplex. After receiving all the replies from the servo driver, send the next command.

The following examples show communication frames with EOT as the end code.

### 3 – 2. Data string format

The communication method uses ASCII codes to send and receive character strings between the host controller and servo driver.

- The numerical information is transmitted as a numeric string in hexadecimal notation with a maximum of 8 characters.
- The axis number should be a 2-digit hexadecimal number.
- For hexadecimal numbers other than axis numbers, the number of characters required to represent the number can be used. There is no need to add leading 0s to align it to a certain length.

However, if the value is negative, be sure to send 8 characters.

Example: Both [00000100] and [100] represent the number "256".

The number "-1" should be represented as [FFFFFFFF]. [FFFF] is interpreted as the number "65535".

- Numerical value in the reply character string from the servo driver to the host controller is sent with a fixed number of characters according to each command.
- When sending strings from the host to the servo driver, either uppercase or lowercase characters can be used for hexadecimal values.

With the parameter N0419 "Communication format select", the uppercase or lowercase hexadecimal alphabetic characters when sending from the servo driver to the host controller can be selected.


### 3 – 3. Single axis command communication

To send a command from the host controller to one of the multiple connected servo drivers, specify the axis number of the target servo driver.

Only the servo driver with the specified axis number will reply to the host controller.

Example of use: 2 axes multidrop communication

- ① servo driver 1 (axis number 01) turn servo ON
- ② servo driver 2 (axis number 03) turn servo ON



※1) Set the time from command reception completion in the servo driver to the start of reply by the servo driver parameter N0420 "Reply wait time" in [ms].

※2) After reply from the servo driver is completed, wait for at least 2ms before sending the next command.

### 3 – 4. All axes command communication


If a command with the axis number "7F" is sent, all servo drivers connected by multidrop will execute the command simultaneously. In this case, no replies from the servo drivers to the host controller are sent, including communication errors.

### 3 – 5. Group command communication

To send a command from the host controller to the group of multiple connected servo drivers, specify the group number ([00]~[0F]) of the target servo drivers.

When specifying a group, the first character of the axis number is "A" and the second character is the group number (0h~Fh).

The group number of the servo driver is set by the parameter N0424 "Serial communication axis group number". For details, refer to the "Parameters" section in the Instruction manual (Main part).



In the group command communication, no replies from the servo drivers to the host controller are sent, including communication errors.


### 3 – 6. Overall command communication

If a command with the axis number [3F] is sent, all servo drivers connected by multidrop will execute the command. Replies to this command are sent in order according to the setting of the parameter "All axis command reply order" of each servo driver.

The replies are sent in order from the servo driver with the lowest number in the parameter N0423 "Serial communication reply order". The servo driver with the parameter value 0 replies first, then the servo driver with 1, next the servo driver with 2, and so on. Assign the numbers 0~(number of multidrop connections - 1) to the parameter N0423 "Serial communication reply order" for each multidrop servo driver without any shortage or duplication. If there are any deficiencies or duplications, the servo driver replies will collide.

Example of use: 3 axes multidrop communication, 3 axes simultaneously EMC turn ON


|                | Axis number | All axis command response order |
|----------------|-------------|---------------------------------|
| servo driver 1 | 5 (05h)     | 00h                             |
| servo driver 2 | 6 (06h)     | 01h                             |
| servo driver 3 | 11 (0Bh)    | 02h                             |



### 3 – 7. Wildcard command communication

If a command with the axis number [9A] is sent, the received servo driver will execute the command regardless of its own axis number. In this case, the returned axis number is the axis number of the servo driver.

Do not use this command for multidrop connections. Multiple servo drivers will reply at the same time, causing collision.



### 3 – 8. Command input method select

By setting the parameter N0006 "Command input method select", the serial communication commands for various operation methods can be enabled / disabled. If a serial communication command for an operation set as invalid for communication command is received, a communication error [ERR;04] (Input method not selected) is returned and the command is not executed.

The setting is made by parameter N0006 "Command input method select" with 2 bits per operation command:

01: Serial communication command

00: Control input

to select from.

Serial communication command setting (set value: 01):

The serial communication command is valid regardless of the control input terminal function setting. (Control input signal is invalid)

Control input setting (set value: 00):

The operation command is given by the control input, and the communication command is invalid.

However, if the control input signal corresponding to each operation command is not assigned to any of the control input terminals IN0~IN4, the serial communication command is valid.

※Only for the servo ON command, if the control input SVON is not assigned, the servo ON state is fixed and the communication command is invalid.

※For the control input signals corresponding to each operation command, refer to the table below.

Table of parameter N0006 "Command input method select" bits sequence

| Bit position | Bit name | Function                         |
|--------------|----------|----------------------------------|
| 31~14        | -        | reserved (write 0)               |
| 13~12        | TSEL     | Torque limit value select        |
| 11~10        | RSEL     | Reference pulse multiply select  |
| 9~8          | PNT      | Point number specify             |
| 7~6          | ZSTR     | Homing operation start/stop      |
| 5~4          | STR      | Point-Table operation start/stop |
| 3~2          | JOG      | Jog operation start/stop         |
| 1~0          | SVON     | Servo ON/OFF                     |

Correspondence between serial communication command and control input for each operation command

| Bit name | Function                  | Serial communication command<br>(set value: 01) | Control input signal<br>(set value: 00)       |
|----------|---------------------------|---|---|
| TSEL     | Torque limit value select | [TSELON] [TSELOFF]<br>[TSEL1ON]~[TSEL4ON]       | TSEL0~TSEL4<br>TSEL0P~TSEL4P<br>TSEL0N~TSEL4N |
| RSEL     | Pulse command multiply    | [RSELON] [RSELOFF]                              | RSEL  |
| PNT      | Point number specify      | [PNT]   | P0_IN~P7_IN                                   |
| ZSTR     | Homing operation          | [ZSTRON] [ZSTROFF] [ZSTRP]                      | ZSTR, ZSTRP                                   |
| STR      | Point-Table operation     | [STRON] [STROFF] [STRP]<br>[STROND] [STRPD]     | STR, STRP                                     |
| JOG      | Jog operation             | [PJOG] [NJOG] [JOGOFF]<br>[PJOGD] [NJOGD]       | PJOG, NJOG                                    |
| SVON     | Servo ON                  | [SVON] [SVOFF]                                  | SVON  |

### 3 – 9. Communication error reply

If the command received by the servo driver is not executed correctly, an error message will be returned to the host controller.

communication error No.

|     |             |   |   |   |   |   |   |   |     |
|-----|-------------|---|---|---|---|---|---|---|-----|
| STX | axis<br>No. | ; | E | R | R | ; | 0 | 1 | EOT |
|-----|-------------|---|---|---|---|---|---|---|-----|

| No. | Content   |
|-----|---|
| 01  | Command error<br>The received command could not be recognized.  |
| 02  | Machine home overwrite failure<br>An attempt was made to execute the machine home overwrite command [ZSET] when the position error exceeded the range of the servo driver parameter N0000 "In-position range", or, an attempt was made to overwrite the machine home [ZSET] to a position above the forward rotation software OT or below the reverse rotation software OT. |
| 03  | Outside the range of input value<br>An attempt was made to enter data that is out of the specified range.   |
| 04  | Input method not selected<br>The received communication command is invalidated by the servo driver according to the parameter N0006 "Command input method select" and control input terminal function setting.  |
| 06  | RESET failure<br>An attempt was made to execute [RESET] command (CPU reset) while the servo was ON.   |
| 07  | Servo ON failure ①<br>An attempt was made to execute [SVON] command while an alarm occurred.  |
| 08  | Servo ON failure ②<br>An attempt was made to execute [SVON] command during emergency stop.  |
| 0B  | Data count mismatch<br>The number of data after the command name in the character string received by the servo driver (separated by the delimiter) does not match the specifications of the command.  |

## 4. Communication commands list

| Function                                       | Command | Content  |
|--|---------|--|
| Parameter read                                 | PR      | Read the contents of Si3 servo driver parameter specified by the number.   |
| Parameter write                                | PW      | Write the Si3 servo driver parameter specified by the number.  |
| Point-Table read                               | PTR     | <ul style="list-style-type: none"> <li>• Point table number (0~255)</li> <li>• Move amount (pulses)</li> <li>• Moving velocity (<math>\text{min}^{-1}</math>)</li> <li>• Acceleration/deceleration time constant (ms)</li> <li>• Wait time (ms)</li> <li>• Branch destination point number (0~255, 256 for end, +1000 for SBK)</li> <li>• Bit command <ul style="list-style-type: none"> <li>BIT0: absolute/relative value (0: absolute, 1: relative)</li> <li>BIT1: continuous operation (0: NO, 1: YES)</li> <li>BIT2: S-curve acceleration/deceleration</li> <li>BIT3: sensor positioning</li> <li>BIT4: sensor positioning</li> <li>BIT6: —</li> <li>BIT7: —</li> <li>BIT8: M code</li> <li>BIT9: M code</li> <li>BITA: M code</li> <li>BITB: M output select</li> </ul> </li> </ul> |
| Point-Table write                              | PTW     | <ul style="list-style-type: none"> <li>• Input branch destination point number (0~255, 256 for end, +1000 for SBK)</li> <li>• Input branch destination point number 2 (0~255, 256 for end, +1000 for SBK)</li> <li>• Input branch destination point number 3 (0~255, 256 for end, +1000 for SBK)</li> <li>• Number of loops</li> <li>• Branch destination point number after loop (0~255, 256 for end, +1000 for SBK)</li> <li>• Torque set (0: none, 1~2000 limit by 0.1% increment)</li> <li>• Loop counter clear</li> <li>(-1: none, 0~255 clear the loop counter of that point number)</li> <li>• Deceleration time constant (ms)</li> </ul> <p>※When input branch destinations 1, 2, 3 are not used, set to "-1".</p>   |
| Point-Table item read                          | PTRS    | Specify point number and item selection (position, velocity, etc.) in the data.  |
| Point-Table item write                         | PTWS    | Specify point number, item selection and write value in the data.  |
| Parameter read (compatible with old models)    | PRMR    | Read the servo driver parameter contents specified by the number. Specify the Si2 parameter number (refer to 6 – 1. Old model (Si servo2) parameters correspondence table).  |
| Parameter write (compatible with old models)   | PRMW    | Overwrite the servo driver parameter specified by the number. Specify the Si2 parameter number (refer to 6 – 1. Old model (Si servo2) parameters correspondence table).  |
| Point-Table read (compatible with old models)  | TR      | The same items are read as with PTR command, except the deceleration time constant.  |
| Point-Table write (compatible with old models) | TW      | The same items are written as with PTW command, except the deceleration time constant.   |
| Data store                                     | FLASH   | Store the parameters and Point-Table data to the non-volatile memory in the driver.  |

| Function                         | Command  | Content  |
|----------------------------------|----------|--|
| Servo ON                         | SVON     | The same functionality as the control input signal SVON.   |
| Servo OFF                        | SVOFF    |  |
| Emergency stop                   | EMCON    | The same functionality as the control input signals EMCF, EMCE.<br>In the data specify 0,1: servo free, 2: control braking.                              |
| Emergency stop release           | EMCOFF   | The same functionality as the control input signals EMCF, EMCE.<br>There is no argument specified for emergency stop release.                            |
| Start Point-Table                | STRON    | The same functionality as the control input signal STR.  |
| Stop Point-Table                 | STROFF   |  |
| Point-Table start edge           | STRP     | The same functionality as the control input signal STRP.   |
| Point-Table specified start      | STROND   | Starts with the specified point table number.<br>Specify the point table number in the data.<br>The same functionality as the control input signal STR.  |
| Point-Table specified start edge | STRPD    | Starts with the specified point table number.<br>Specify the point table number in the data.<br>The same functionality as the control input signal STRP. |
| Homing start                     | ZSTRON   | The same functionality as the control input signal ZSTR.   |
| Homing stop                      | ZSTROFF  |  |
| Homing start edge                | ZSTRP    | The same functionality as the control input signal ZSTRP.  |
| Operation stop                   | STOP     | The same functionality as the control input signal STP.  |
| Home deceleration ON             | DECON    | The same functionality as the control input signal DEC.  |
| Home deceleration OFF            | DECOFF   |  |
| Pause                            | HOLDON   | The same functionality as the control input signal HOLD.   |
| Pause release                    | HOLDOFF  |  |
| Single block ON                  | SBKON    | The same functionality as the control input signal SBK.  |
| Single block OFF                 | SBKOFF   |  |
| Input branch ON                  | EXINON   | Select 1~3 in the data.  |
| Input branch OFF                 | EXINOFF  | The same functionality as the communication commands [EXIN1ON]~[3ON], [EXIN1OFF]~[3OFF].<br>If no data, [EXINON][EXINOFF] is executed.                   |
| Input branch 1 ON                | EXIN1ON  | The same functionality as the control input signal EXIN.   |
| Input branch 1 OFF               | EXIN1OFF |  |
| Input branch 2 ON                | EXIN2ON  | The same functionality as the control input signal EXIN2.  |
| Input branch 2 OFF               | EXIN2OFF |  |
| Input branch 3 ON                | EXIN3ON  | The same functionality as the control input signal EXIN3.  |
| Input branch 3 OFF               | EXIN3OFF |  |
| Forward jog start                | PJOG     | JOG operation is performed in forward direction.   |
| Reverse jog start                | NJOG     | JOG operation is performed in reverse direction.   |
| Stop jog operation               | JOGOFF   | Stop JOG operation.  |
| Teaching                         | TDIN     | Current position is stored in "Move amount" of the point number specified by PNT command.  |
| Alarm reset                      | ARST     | The same functionality as the control input signal ARST.   |
| Torque peak reset                | TRST     | Reset the torque peak.   |
| Point number specify             | PNT      | The same functionality as the control input signals P0_IN~P7_IN.   |
| Alarm history clear              | HCL      | Clear alarm histories.   |
| CPU reset                        | RESET    | Turn the power OFF-ON (power cycle).   |
| Current position set             | ZSET     | Specify the coordinate value of current position. (overwrite the mechanical home).   |
| Position error set               | ESET     | Set or clear the position error counter.   |

|                          | Function  | Command  | Content   |
|--------------------------|---|--|---|
| Basic operation          | Resolution select ON                                | RSELON   | The same functionality as the control input signal RSEL.  |
|                          | Resolution select OFF                               | RSELOFF  |   |
|                          | Torque select                                       | TSELON   | Select 0~4 in the data.<br>The same functionality as the communication commands [TSEL0ON]~[4ON]. If no data, [TSEL0ON] is executed.   |
|                          | Torque deselect                                     | TSELOFF  | Cancels the torque selection.   |
|                          | Torque select 0 ON                                  | TSEL0ON  | The same functionality as the control input signal TSEL0.   |
|                          | Torque select 1 ON                                  | TSEL1ON  | The same functionality as the control input signal TSEL1.   |
|                          | Torque select 2 ON                                  | TSEL2ON  | The same functionality as the control input signal TSEL2.   |
|                          | Torque select 3 ON                                  | TSEL3ON  | The same functionality as the control input signal TSEL3.   |
|                          | Torque select 4 ON                                  | TSEL4ON  | The same functionality as the control input signal TSEL4.   |
|                          | M complete ON                                       | MFINON   | The same functionality as the control input signal MFIN.  |
|                          | M complete OFF                                      | MFINOFF  |   |
|                          | Step operation start                                | STEPON   | Select 0~3 in the data. The same functionality as the communication commands [STEP0ON]~[3ON].<br>If no data, the same operation as [STEP0ON] is executed.                                 |
|                          | Step operation stop                                 | STEPOFF  | Stop the step operation.  |
|                          | Step operation 0 start                              | STEP0ON  | Move for the set value (pulses) of "Step operation pulses 0".<br>Maximum velocity and acc/dec are the same as for JOG operation.  |
|                          | Step 0 forward start                                | STEP0P   | Move in forward direction for the set value of "Step operation pulses 0".   |
|                          | Step 0 reverse start                                | STEP0N   | Move in reverse direction for the set value of "Step operation pulses 0".   |
|                          | Step 1 start  | STEP1ON  | Move for the set value (pulses) of "Step operation pulses 1".<br>Maximum speed and acceleration/deceleration are the same as for JOG operation.   |
|                          | Step 1 forward start                                | STEP1P   | Move in forward direction for the set value of "Step operation pulses 1".   |
|                          | Step 1 reverse start                                | STEP1N   | Move in reverse direction for the set value of "Step operation pulses 1".   |
|                          | Step operation 2 start                              | STEP2ON  | Move for the set value (pulses) of "Step operation pulses 2".<br>Maximum speed and acceleration/deceleration are the same as for JOG operation.   |
|                          | Step 2 forward start                                | STEP2P   | Move in forward direction for the set value of "Step operation pulses 2".   |
|                          | Step 2 reverse start                                | STEP2N   | Move in reverse direction for the set value of "Step operation pulses 2".   |
|                          | Step operation 3 start                              | STEP3ON  | Move for the set value (pulses) of "Step operation pulses 3".<br>Maximum velocity and acceleration/deceleration are the same as for JOG operation.  |
|                          | Step 3 forward start                                | STEP3P   | Move in forward direction for the set value of "Step operation pulses 3".   |
|                          | Step 3 reverse start                                | STEP3N   | Move in reverse direction for the set value of "Step operation pulses 3".   |
|                          | Transition to sensor input standby state            | SLREQON  | Transition to the sensor input standby state.   |
|                          | Cancel sensor input standby state                   | SLREQOFF   | Cancels the sensor input standby state.   |
| Direct positioning start | DPS   | Starts profile positioning.<br>Specify the target position, velocity, and acceleration/deceleration in the data. |   |
| Monitor                  | Numerical value monitor                             | MON  | Specify the monitor item as data.   |
|                          | Read alarm information (compatible with old models) | ALM  | Current alarm and history of the past 8 alarms is returned.<br>Read the bit status corresponding to the generated alarm number.   |
|                          | I/O monitor   | IO2  | Monitors the status of control input/output terminals.  |
|                          | Alarm read  | ALMP   | Read the list of currently occurring alarms.  |
|                          | Alarm history read                                  | ALHP   | Read the alarms list that have occurred in the past.  |
|                          | Monitor · diagnostic information read               | DIAG   | Specify the diagnostic information number (0~31) and monitor number (0~255) in the data.<br>diagnostic information number 0: current, 1~31: diagnostic information when an alarm occurred |

## 5. Communication commands details

### 5 – 1. Parameters/Point-Table setting commands

Note) Numeric hexadecimal values other than the axis number can be represented by the number of characters required to represent the value (it is not necessary to add zeros to the beginning to align them to a certain length). However, if the value is negative, be sure to send 8 characters.

Example: Both [00000100] and [100] represent the number "256".

The number "-1" should be represented as [FFFFFFFF]. [FFFF] is interpreted as the number "65535".

Numerical value in the reply character string from the servo driver to the host controller is sent with a fixed number of characters according to each command.

#### 5 – 1 – 1. [PR] [PRMR] Parameter read

[PR] command reads the values of parameters N0000~N0435.

Example) Read the parameter N0100 from Si3 servo driver with axis number 3.

host controller ⇒ Si3 servo driver

|              | axis number |    |    | command parameter number [N0100 (64h)] |    |    |    |    |    |     |
|--------------|-------------|----|----|--|----|----|----|----|----|-----|
| (ASCII code) | STX         | 0  | 3  | ;                                      | P  | R  | ;  | 6  | 4  | EOT |
|              | 02          | 30 | 33 | 3B                                     | 50 | 52 | 3B | 36 | 34 | 04  |

Si3 servo driver ⇒ host controller

|  | parameter value [hexadecimal 8 characters] |   |   |   |   |   |   |   |   |   |   |   |   |   |   |     |
|--|--|---|---|---|---|---|---|---|---|---|---|---|---|---|---|-----|
|  | STX  | 0 | 3 | ; | P | R | ; | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | EOT |
|  | (read result 1)                            |   |   |   |   |   |   |   |   |   |   |   |   |   |   |     |

(Commands for compatibility with old models)

[PRMR] is a command for compatibility with old models. With this command, the parameter numbers 0~79 of Si servo2 are specified, and the values of corresponding function parameters (N0000~N0435) of Si servo3 are read. If Si servo2 driver is replaced with Si servo3, the system can continue to use [PRMR] command issued by the host controller.

※For details on [PRMR] command sending and receiving data, refer to the Si servo2 Instruction manual (Communication part).

※For details on the parameters correspondence between Si servo2 and Si servo3, refer to 6 – 1.

Old model (Si servo2) parameters correspondence table.


## 5 – 1 – 2 . [PW] [PRMW] Parameter write

[PW] command overwrites the values of servo driver parameters N0000~N0435.

The parameter value set by this command will not be retained after the power is turned off. Execute [FLASH] command to store the set value.

Example) Write 1 (01h) to the parameter No.0100 of Si3 servo driver with axis number 3.

host controller ⇒ Si3 servo driver



Si3 servo driver ⇒ host controller



(Commands for compatibility with old models)

[PRMW] is a command for compatibility with old models. With this command, the parameter numbers 0~79 of Si servo2 are specified, and the values of corresponding function parameters (N0000~N0435) of Si servo3 are written. If Si servo2 driver is replaced with Si servo3, the system can continue to use [PRMW] command issued by the host controller.

※For details on [PRMW] command sending and receiving data, refer to the Si servo2 Instruction manual (Communication part).

※For details on the parameters correspondence between Si servo2 and Si servo3, refer to 6 – 1 .

Old model (Si servo2) parameters correspondence table.

## 5 - 1 - 3. [PTR] [TR] Point-Table read

Read the contents of Point-Table No.0~255 from the servo driver.

With [TR] command for compatibility with old models, items other than the deceleration time constant are read. When replacing Si servo2 with Si servo3, [TR] command issued by the host controller can be used as previously.

Note 1) Some data such as absolute position, relative value are handled collectively as a bit command.

For details, refer to the table below [Bit command details].

Bit command details

| Bit position | Item                              | Content  |                  |
|--------------|-----------------------------------|--|------------------|
|              |                                   | 0  | 1                |
| BIT0         | Absolute value/Relative value     | Absolute value   | Relative value   |
| BIT1         | Continuous operation              | none   | YES              |
| BIT2         | S-curve acceleration/deceleration | none   | YES              |
| BIT3         | Sensor positioning                | BIT4,3 00: none 01: sensor positioning 1<br>10: sensor positioning 2   |                  |
| BIT4         |                                   |  |                  |
| BIT5         | - Branch signal level input (※)   | edge   | level            |
| BIT6         | —                                 | —  | —                |
| BIT7         | —                                 | —  | —                |
| BIT8         | M code                            | BIT8,9,A 000: none 001: M code 1<br>010: M code 2 011: M code 3 100: M code 4<br>101: M code 5 110: M code 6 111: M code 7 |                  |
| BIT9         |                                   |  |                  |
| BITA         |                                   |  |                  |
| BITB         | M output selection                | before points start  | after points end |
| BITC         | —                                 | —  | —                |
| BITD         | —                                 | —  | —                |
| BITE         | —                                 | —  | —                |
| BITF         | —                                 | —  | —                |

(※) This data is valid only for Si servo3.

Example) Read the contents of point number 154 from a servo driver with axis number 3

host controller ⇒ Si3 servo driver

|              | axis number |    |    |    | point number |    |    |    |    |    |     |
|--------------|-------------|----|----|----|--------------|----|----|----|----|----|-----|
| (ASCII code) | STX         | 0  | 3  | ;  | P            | T  | R  | ;  | 9  | A  | EOT |
|              | 02          | 30 | 33 | 3B | 50           | 55 | 52 | 3B | 39 | 41 | 04  |

Si3 servo driver ⇒ host controller

|  | axis number           |   |   |   | move amount         |   |   |                         |   |   | moving velocity                |   |   |   |   |   |   |   |   |     |   |   |
|--|-----------------------|---|---|---|---------------------|---|---|-------------------------|---|---|--------------------------------|---|---|---|---|---|---|---|---|-----|---|---|
|  | STX                   | 0 | 3 | ; | P                   | T | R | ;                       | 0 | 0 | 0                              | 2 | E | 3 | 1 | 1 | ; | 0 | 1 | F   | 4 | ; |
|  | acc/dec time constant |   |   |   | wait time           |   |   | normal branch           |   |   | bit command <sup>Note 1)</sup> |   |   |   |   |   |   |   |   |     |   |   |
|  | 0                     | 0 | 6 | 4 | ;                   | 0 | 3 | E                       | 8 | ; | 0                              | 0 | 0 | C | ; | 0 | 0 | 0 | 7 | ;   |   |   |
|  | input branch 1 (※2)   |   |   |   | input branch 2 (※2) |   |   | input branch 3 (※2)     |   |   | number of loops                |   |   |   |   |   |   |   |   |     |   |   |
|  | F                     | F | F | F | ;                   | F | F | F                       | F | ; | F                              | F | F | F | ; | 0 | 0 | 0 | A | ;   |   |   |
|  | branch after loop     |   |   |   | torque              |   |   | loop counter clear (※2) |   |   | dec time constant (※1)         |   |   |   |   |   |   |   |   |     |   |   |
|  | 0                     | 0 | 9 | 0 | ;                   | 0 | 0 | 0                       | 0 | ; | F                              | F | F | F | ; | 0 | 0 | 3 | 2 | EOT |   |   |

(※1) Deceleration time constant is the data of [PTR] command only.

(※2) [FFFF](h) is returned when the input branch destinations 1~3 and the loop counter clear values are "-1" (not used).

## 5 - 1 - 4. [PTW] [TW] Point-Table write

Overwrite the contents of servo driver Point-Table No.0~255.

The [TW] command for compatibility with old models writes the data other than the deceleration time constant (the value set for acceleration/deceleration time constant is applied as the deceleration time constant).

When replacing Si servo2 with Si servo3, [TW] command issued by the host controller can be used as previously.

The position data set by this command will not be retained after the power is turned off. Execute [FLASH] command to store the set value.

Note 1) Some data such as absolute position, relative value are handled collectively as a bit command.

For details, refer to "[PTR] [TR] Point-Table read" table [Bit command details].

Example) Write to point number 2 of Si3 servo with axis number 3

host controller ⇒ Si3 servo driver

|              |  | command                        |    |    |    |    |    |    | point number            |    |    |    | move amount                     |    |               |    |    |    |    |     |    |    |    |    |    |    |
|--------------|--|--------------------------------|----|----|----|----|----|----|-------------------------|----|----|----|---------------------------------|----|---------------|----|----|----|----|-----|----|----|----|----|----|----|
| (ASCII code) |  | STX                            | 0  | 3  | ;  | P  | T  | W  | ;                       | 0  | 2  | ;  | 0                               | 0  | 0             | 2  | E  | 3  | 1  | 1   | ;  |    |    |    |    |    |
|              |  | 02                             | 30 | 33 | 3B | 50 | 54 | 57 | 3B                      | 30 | 32 | 3B | 30                              | 30 | 30            | 32 | 45 | 33 | 31 | 31  | 3B |    |    |    |    |    |
|              |  | moving velocity                |    |    |    |    |    |    | acc/dec time constant   |    |    |    | wait time                       |    | normal branch |    |    |    |    |     |    |    |    |    |    |    |
|              |  | 0                              | 7  | D  | 0  | ;  | 0  | 1  | F                       | 4  | ;  | 0  | 3                               | E  | 8             | ;  | 0  | 0  | 1  | 4   | ;  |    |    |    |    |    |
|              |  | 30                             | 37 | 44 | 30 | 3B | 30 | 31 | 46                      | 34 | 3B | 30 | 33                              | 45 | 38            | 3B | 30 | 33 | 31 | 38  | 3B |    |    |    |    |    |
|              |  | bit command <sup>Note 1)</sup> |    |    |    |    |    |    | input branch 1 (※2)     |    |    |    | input branch 2 (※2)             |    |               |    |    |    |    |     |    |    |    |    |    |    |
|              |  | 0                              | 0  | 0  | 3  | ;  | 0  | 0  | 0                       | 0  | 0  | 0  | 0                               | B  | ;             | F  | F  | F  | F  | F   | F  | F  | F  | F  | F  | ;  |
|              |  | 30                             | 30 | 30 | 33 | 3B | 30 | 30 | 30                      | 30 | 30 | 30 | 30                              | 42 | 3B            | 46 | 46 | 46 | 46 | 46  | 46 | 46 | 46 | 46 | 46 | 3B |
|              |  | input branch 3 (※2)            |    |    |    |    |    |    | number of loops         |    |    |    | branch after loop               |    |               |    |    |    |    |     |    |    |    |    |    |    |
|              |  | F                              | F  | F  | F  | F  | F  | F  | F                       | ;  | 0  | 5  | ;                               | 0  | 1             | 0  | 0  | ;  |    |     |    |    |    |    |    |    |
|              |  | 46                             | 46 | 46 | 46 | 46 | 46 | 46 | 46                      | 3B | 30 | 35 | 3B                              | 30 | 31            | 30 | 30 | 3B |    |     |    |    |    |    |    |    |
|              |  | torque                         |    |    |    |    |    |    | loop counter clear (※2) |    |    |    | deceleration time constant (※1) |    |               |    |    |    |    |     |    |    |    |    |    |    |
|              |  | 0                              | 0  | 0  | 0  | ;  | F  | F  | F                       | F  | F  | F  | F                               | F  | ;             | 0  | 1  | F  | 4  | EOT |    |    |    |    |    |    |
|              |  | 30                             | 30 | 30 | 30 | 3B | 46 | 46 | 46                      | 46 | 46 | 46 | 46                              | 46 | 3B            | 30 | 31 | 46 | 34 | 04  |    |    |    |    |    |    |

Si3 servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | T | W | EOT |
|-----|---|---|---|---|---|---|-----|

(※1) Deceleration time constant is the data of [PTR] command only.

(※2) When not using the input branch destination (1~3) and loop counter clear, set the corresponding items to "-1", that is, to [FFFFFFF](h).

## 5 - 1 - 5. [PTRS] Point-Table item read

Read the contents corresponding to the specified item from the specified point in Point-Table.

Item codes list

| Code | Item                                    |
|------|---|
| 00   | Move amount                             |
| 01   | Velocity                                |
| 02   | Acceleration/deceleration time constant |
| 03   | Wait time                               |
| 04   | Normal branch destination               |
| 05   | Bit command (※)                         |
| 06   | Input branch destination 1              |
| 07   | Input branch destination 2              |
| 08   | Input branch destination 3              |
| 09   | Number of loops                         |
| 0A   | Branch destination point                |
| 0B   | Torque set                              |
| 0C   | Loop counter clear                      |
| 0D   | Deceleration time constant              |

(※) For bit command details refer to "Bit command details" in PTR, TR commands description.

Example) Read the content "Move amount" of point number 154 from a servo driver with axis number 3

host controller ⇒ Si3 servo driver

|              | axis number |    |    |    | point number |    |    |    |    | read code |    |    |    |    |     |
|--------------|-------------|----|----|----|--------------|----|----|----|----|-----------|----|----|----|----|-----|
| (ASCII code) | STX         | 0  | 3  | ;  | P            | T  | R  | S  | ;  | 9         | A  | ;  | 0  | 0  | EOT |
|              | 02          | 30 | 33 | 3B | 50           | 52 | 52 | 53 | 39 | 41        | 39 | 39 | 41 | 04 |     |

Si3 servo driver ⇒ host controller

|  | axis number |   |   |   | move amount |   |   |   |   |   |   |   |   |   |   |   |   |     |
|--|-------------|---|---|---|-------------|---|---|---|---|---|---|---|---|---|---|---|---|-----|
|  | STX         | 0 | 3 | ; | P           | T | R | S | ; | 0 | 0 | 0 | 2 | E | 3 | 1 | 1 | EOT |

## 5 - 1 - 6. [PTWS] Point-Table item write

Write data to the specified item of the specified point in Point-Table.

The position data set by this command will not be retained after the power is turned off. Execute [FLASH] command to store the set value.

Note 1) For item code details refer to "[PTR] [TR] Point-Table read" table [Bit command details].

Example) Write moving velocity to point number 2 of Si3 servo with axis number 3

host controller ⇒ Si3 servo driver

|              |     | command |    |    |    | point number |    |    | code | moving velocity |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|---------|----|----|----|--------------|----|----|------|-----------------|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0       | 3  | ;  | P  | T            | W  | S  | ;    | 0               | 2  | ;  | 0  | 1  | ;  | 0  | 7  | D  | 0  | EOT |
|              | 02  | 30      | 33 | 3B | 50 | 54           | 57 | 53 | 3B   | 30              | 32 | 3B | 30 | 31 | 3B | 30 | 37 | 44 | 30 | 04  |

Si3 servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | T | W | S | EOT |
|-----|---|---|---|---|---|---|---|-----|

※When not using the input branch (1~3) and loop counter clear, set the corresponding items to "1", that is to [FFFFFFFF](h).

## 5 – 1 – 7. [FLASH] EEPROM write

Store the data set by [PW], [PRMW], [PTW], [TW], and [TDIN] commands in the servo driver nonvolatile memory. The stored values are retained after the power is turned off.

Nonvolatile memory can nominally be rewritten 100,000 times.

Example) Store the data (parameters, point table data) of a servo driver with axis number 3

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | F  | L  | A  | S  | H  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 46 | 4C | 41 | 53 | 48 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | F | L | A | S | H | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

## 5 – 2 . Basic operation commands

### 5 – 2 – 1 . [SVON] [SVOFF] Servo ON/OFF

The same functionality as turning ON/OFF the control input signal SVON.

※When using this command, enable the communication command for SVON (servo ON/OFF) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device                           |
|----------|------|-----------|---|
| SVON     | BIT1 | 0         | communication command<br>[SVON] [SVOFF] |
|          | BIT0 | 1         |   |

Example) Turn servo ON, servo OFF of a servo driver with axis number 3

[SVON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | S  | V  | O  | N  | EOT |
|              | 02  | 30 | 33 | 3B | 53 | 56 | 4F | 4E | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | V | O | N | EOT |
|-----|---|---|---|---|---|---|---|-----|

[SVOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | S  | V  | O  | F  | F  | EOT |
|              | 02  | 30 | 33 | 3B | 53 | 56 | 4F | 46 | 46 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | V | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

#### ★[SVON] and [SVOFF] commands usage precautions

The servo ON command by the communication command [SVON] is held in the driver. When the servo is turned ON by [SVON] and the servo is forcibly turned OFF by alarm or emergency stop, and then the alarm/emergency stop is released, the servo ON command is retained internally and the servo is turned ON again.

If the communication command [SVOFF] is executed while the servo is OFF due to alarm or emergency stop, the internally held servo ON command will be released and the servo OFF state will be kept even after the alarm/emergency stop is released.

## 5 - 2 - 2. [EMCON] [EMCOFF] Emergency stop ON/OFF

When a servo driver receives [EMCON] command, the motor will perform emergency stop operation.

The emergency stop operation changes depending on the data added to the command.

| Send string | Emergency stop operation |
|-------------|--------------------------|
| EMCON       | servo free               |
| EMCON;0     |                          |
| EMCON;1     |                          |
| EMCON;2     | control braking          |

Example) Emergency stop (control braking) and release in a servo driver with axis number 3

[EMCON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | M  | C  | O  | N  | ;  | 2  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 4D | 43 | 4F | 4E | 3B | 32  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | M | C | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

If this is omitted, [EMCON;0] is executed.

[EMCOFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | M  | C  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 4D | 43 | 4F | 46 | 46  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | M | C | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 3 . [STRON] [STROFF] [STRP] Point-Table start ON/OFF

[STRON] and [STRP] commands activate Point-Table operation.

Specify in advance the Point-Table number to be activated using the control inputs P0\_IN ~P7\_IN or [PNT] command.

[STROFF] command stops the point table operation started by [STRON] or [STROND] commands.

※When using this command, enable the communication command for STR (Point-Table operation start/stop) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device                                    |
|----------|------|-----------|--|
| STR      | BIT5 | 0         | communication command<br>[STRON] [STROFF] [STRP] |
|          | BIT4 | 1         |  |

Example) Start and stop Point-Table No.5 of a servo driver with axis number 3 [PNT] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | P  | N  | T  | ;  | 0  | 5  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 50 | 4E | 54 | 3B | 30 | 35  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | N | T | EOT |
|-----|---|---|---|---|---|---|-----|

[STRON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | R  | O  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 53 | 54 | 52 | 4F | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | R | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

[STROFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | R  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 53 | 54 | 52 | 4F | 46 | 46  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | R | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

[STRP] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | R  | P  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 53 | 54 | 52 | 50  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | R | P | EOT |
|-----|---|---|---|---|---|---|---|-----|

#### ★Differences between [STRON] and [STRP] commands and usage precautions

- The Point-Table operation start command [STRON] is held in the servo driver as a level signal. By canceling this signal with [STROFF] command, the running Point-Table operation is stopped.
- The Point-Table operation start command [STRP] is a one-shot signal and is not held in the servo driver. Use [STOP] command to stop the Point-Table operation started by [STRP] command.
- The Point-Table operation start command [STRON] is held in the servo driver as a level signal. Therefore, after the Point-Table operation started by [STRON] command ends (normal end or forced stop due to alarm or emergency stop) it is necessary to send [STROFF] command before sending next [STRON]. [STROFF] is not required when operation is started with [STRP].

## 5 – 2 – 4 . [STROND] [STRPD] Point-Table specified start

[STROND] and [STRPD] commands specify the Point-Table number and start the operation.

Use [STROFF] command to stop the Point-Table operation started by [STROND] command.

※When using this command, enable the communication command for STR (Point-Table operation start/stop) and PNT (Point number specify) functions by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device         |
|----------|------|-----------|-----------------------|
| PNT      | BIT9 | 0         | communication command |
|          | BIT8 | 1         |                       |
| STR      | BIT5 | 0         | communication command |
|          | BIT4 | 1         |                       |

Example) Start and stop Point-Table No.5 of a servo driver with axis number 3

[STROND] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | S  | T  | R  | O  | N  | D  | ;  | 0  | 5  | EOT |
|              | 02  | 30 | 33 | 3B | 53 | 54 | 52 | 4F | 4E | 44 | 3B | 30 | 35 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | R | O | N | D | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

[STRPD] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | S  | T  | R  | P  | D  | ;  | 0  | 5  | EOT |
|              | 02  | 30 | 33 | 3B | 53 | 54 | 52 | 50 | 44 | 3B | 30 | 35 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | R | P | EOT |
|-----|---|---|---|---|---|---|---|-----|

### ★Differences between [STROND] and [STRPD] commands and usage precautions

- The Point-Table operation start command [STROND] is held in the servo driver as a level signal. By canceling this signal with [STROFF] command, the running Point-Table operation is stopped.
- The Point-Table operation start command [STRPD] is a one-shot signal and is not held in the servo driver. Use [STOP] command to stop the Point-Table operation started by [STRPD] command.
- The Point-Table operation start command [STROND] is held in the servo driver as a level signal. Therefore, after the Point-Table operation started by [STROND] command ends (normal end or forced stop due to alarm or emergency stop) it is necessary to send [STROFF] command before sending next [STROND]. [STROFF] is not required when operation is started with [STRPD].

### 5 – 2 – 5 . [ZSTRON] [ZSTROFF] [ZSTRP] Homing start ON/OFF

The same functionality as turning ON or OFF the control input signal ZSTR (ZSTRP). If the servo driver receives [ZSTRON] command while the servo is ON, the homing operation will start according to the selected method in the servo driver parameter "Homing method".

If a servo driver receives [ZSTROFF] command during the homing operation started by [ZSTRON], the motor will decelerate and stop. In this case, the homing is not completed yet, thus perform a homing again before starting operation.

Use [STOP] command to interrupt the homing operation started by [ZSTRP].

After the homing operation started by [ZSTRON] is normally completed or after the homing operation is forcibly stopped by an alarm or emergency stop, [ZSTROFF] must be executed before next [ZSTRON] command. [ZSTROFF] is not required when operation is started with [ZSTRP].

※When using this command, enable the communication command for ZSTR (Homing operation start/stop) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device                                     |
|----------|------|-----------|---|
| ZSTR     | BIT7 | 0         | communication command<br>[ZSTRON][ZSTROFF][ZSTRP] |
|          | BIT6 | 1         |   |

Example) Homing start and stop of a servo driver with axis number 3

[ZSTRON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | Z  | S  | T  | R  | O  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 5A | 53 | 54 | 52 | 4F | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | Z | S | T | R | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

[ZSTROFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | Z  | S  | T  | R  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 5A | 53 | 54 | 52 | 4F | 46 | 46  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | Z | S | T | R | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

[ZSTP] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |     |
|--------------|----|----|----|----|----|----|----|----|-----|
| STX          | 0  | 3  | ;  | Z  | S  | T  | R  | P  | EOT |
| (ASCII code) | 02 | 30 | 33 | 3B | 5A | 53 | 54 | 50 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | Z | S | T | R | P | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 6 . [STOP] Stop operation

The same functionality as the control input signal STP.

If the servo driver receives [STOP] command during point operation, homing, or JOG operation, the operation will be interrupted and the motor will decelerate and stop.

If point operation is in progress, the remaining move amount will be cleared after stopping.

If the homing is in progress, the homing will remain incomplete.

Example) Stop operation of a servo driver with axis number 3

|                                |     |    |    |    |    |    |    |    |     |  |
|--------------------------------|-----|----|----|----|----|----|----|----|-----|--|
| host controller ⇒ servo driver |     |    |    |    |    |    |    |    |     |  |
|                                | STX | 0  | 3  | ;  | S  | T  | O  | P  | EOT |  |
| (ASCII code)                   | 02  | 30 | 33 | 3B | 53 | 54 | 4F | 50 | 04  |  |
| servo driver ⇒ host controller |     |    |    |    |    |    |    |    |     |  |
|                                | STX | 0  | 3  | ;  | S  | T  | O  | P  | EOT |  |

### 5 – 2 – 7 . [DECON] [DECOFF] Home deceleration LS ON/OFF

The same functionality as turning ON/OFF the control input signal DECON.

Example) Activate and deactivate home deceleration of a servo driver with axis number 3

[DECON] command

|                                |     |    |    |    |    |    |    |    |    |     |
|--------------------------------|-----|----|----|----|----|----|----|----|----|-----|
| host controller ⇒ servo driver |     |    |    |    |    |    |    |    |    |     |
|                                | STX | 0  | 3  | ;  | D  | E  | C  | O  | N  | EOT |
| (ASCII code)                   | 02  | 30 | 33 | 3B | 44 | 45 | 43 | 4F | 4E | 04  |
| servo driver ⇒ host controller |     |    |    |    |    |    |    |    |    |     |
|                                | STX | 0  | 3  | ;  | D  | E  | C  | O  | N  | EOT |

[DECOFF] command

|                                |     |    |    |    |    |    |    |    |    |    |     |
|--------------------------------|-----|----|----|----|----|----|----|----|----|----|-----|
| host controller ⇒ servo driver |     |    |    |    |    |    |    |    |    |    |     |
|                                | STX | 0  | 3  | ;  | D  | E  | C  | O  | F  | F  | EOT |
| (ASCII code)                   | 02  | 30 | 33 | 3B | 44 | 45 | 43 | 4F | 46 | 46 | 04  |
| servo driver ⇒ host controller |     |    |    |    |    |    |    |    |    |    |     |
|                                | STX | 0  | 3  | ;  | D  | E  | C  | O  | F  | F  | EOT |

### 5 – 2 – 8 . [HOLDON] [HOLDOFF] Pause (HOLD) ON/OFF

The same functionality as turning ON or OFF the control input signal HOLD. If the servo driver receives [HOLDON] command during the point positioning operation, it will decelerate and stop while holding the remaining move amount. When [HOLDOFF] is received, the point positioning operation that was being executed before the pause is continued.

Example) Pause and continue point positioning operation of a servo driver with axis number 3

#### [HOLDON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | H  | O  | L  | D  | O  | N  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 48 | 4F | 4C | 44 | 4F | 4E | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | H | O | L | D | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

#### [HOLDOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | H  | O  | L  | D  | O  | F  | F  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 48 | 4F | 4C | 44 | 4F | 46 | 46 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | H | O | L | D | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 9 . [SBKON] [SBKOFF] Single block ON/OFF

The same functionality as turning ON or OFF the control input signal SBK. When the "Normal/Input branch destination" item in the Point-Table is set to a value in 1000~1255, a single block operation is performed with this command.

Example) Turn ON and OFF the single block signal input of a servo driver with axis number 3

#### [SBKON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | S  | B  | K  | O  | N  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 53 | 42 | 4B | 4F | 4E | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | B | K | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|-----|

#### [SBKOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | S  | B  | K  | O  | F  | F  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 53 | 42 | 4B | 4F | 46 | 46 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | B | K | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

## 5 - 2 - 1 0. [EXINON] [EXINOFF] [EXIN1ON] [EXIN1OFF] [EXIN2ON] [EXIN2OFF] [EXIN3ON] [EXIN3OFF] Input branch ON/OFF

The same functionality as turning ON or OFF the control input signals EXIN, EXIN2, EXIN3. This command is valid when the input condition jump is set in Point-Table.

[EXINON] and [EXINOFF] commands with arguments 1~3 turn ON and OFF the control input signals EXIN, EXIN2, and EXIN3.

Example) Turn input branch 2 ON and OFF in a servo driver with axis number 3

<Example 1> Turn EXIN2 ON and OFF with [EXINON] [EXINOFF] commands

### [EXINON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | X  | I  | N  | O  | N  | ;  | 2  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 58 | 49 | 4E | 4F | 4E | 3B | 32  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | X | I | N | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

### [EXINOFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | X  | I  | N  | O  | F  | F  | ;  | 2  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 58 | 49 | 4E | 4F | 46 | 46 | 3B | 32  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | X | I | N | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

<Example 2> Turn EXIN2 ON and OFF with [EXIN2ON] [EXIN2OFF] command

### [EXIN2ON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | X  | I  | N  | 2  | O  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 58 | 49 | 4E | 32 | 4F | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | X | I | N | 2 | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

### [EXIN2OFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | E  | X  | I  | N  | 2  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 45 | 58 | 49 | 4E | 32 | 4F | 46 | 46  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | E | X | I | N | 2 | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|---|-----|

## 5 – 2 – 1 1. [PJOG] [NJOG] [JOGOFF] JOG operation

[PJOG] command starts jog operation in forward direction, and [NJOG] command starts jog operation in reverse direction.

[JOGOFF] command stops the jog operation started by [PJOG], [NJOG], [PJOGD] or [NJOGD] commands.

※When using this command, enable the communication command for JOG (Jog operation start/stop) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8. Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device                                   |
|----------|------|-----------|---|
| JOG      | BIT3 | 0         | communication command<br>[PJOG] [NJOG] [JOGOFF] |
|          | BIT2 | 1         |   |

Example) Jog operation of a servo driver with axis number 3

[PJOG] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | P  | J  | O  | G  | EOT |
|              | 02  | 30 | 33 | 3B | 50 | 4A | 4F | 47 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | J | O | G | EOT |
|-----|---|---|---|---|---|---|---|-----|

[NJOG] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | N  | J  | O  | G  | EOT |
|              | 02  | 30 | 33 | 3B | 4E | 4A | 4F | 47 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | N | J | O | G | EOT |
|-----|---|---|---|---|---|---|---|-----|

[JOGOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | J  | O  | G  | O  | F  | F  | EOT |
|              | 02  | 30 | 33 | 3B | 4A | 4F | 47 | 4F | 46 | 46 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | J | O | G | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

### ★[PJOG] and [NJOG] commands usage precautions

- The jog operation start [PJOG] and [NJOG] commands are held in the servo driver as level signals. Therefore, after the jog operation started by [PJOG] or [NJOG] command ends due to alarm or emergency stop it is necessary to send [JOGOFF] command before sending next [PJOG] or [NJOG].

### 5 – 2 – 1 2. [TDIN] Teaching

The same functionality as the control input signal TDIN. Used in combination with [PNT] command. When the servo driver receives [TDIN] command, it sets (teaching) the current position to the "Move amount" of the point number specified by the [PNT] command. In addition, the "Absolute/relative value" of the point number where the teaching was performed is automatically set to 0 (absolute value). The position data set by this command will not be retained after the power is turned off, similar to [PRMW] [TBLW] [TW] commands. Execute [FLASH] command to store the set value.

Example) Set the current position at 123456 pulses to point No.5 of a servo driver with axis number 3 (123456 (1E240h) [pulses] is set)

[PNT] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | P  | N  | T  | ;  | 0  | 5  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 50 | 4E | 54 | 3B | 30 | 35  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | N | T | EOT |
|-----|---|---|---|---|---|---|-----|

[TDIN] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | T  | D  | I  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 54 | 44 | 49 | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |
|-----|---|---|---|---|---|---|---|
| STX | 0 | 3 | ; | T | D | I | N |
|-----|---|---|---|---|---|---|---|

|   |   |   |   |   |   |   |   |   |   |   |   |     |
|---|---|---|---|---|---|---|---|---|---|---|---|-----|
| ; | 0 | 5 | ; | 0 | 0 | 0 | 1 | E | 2 | 4 | 0 | EOT |
|---|---|---|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 1 3. [ARST] Alarm reset

Currently occurring alarms that can be released will be released.

[ARST] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | A  | R  | S  | T  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 41 | 52 | 53 | 54  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | A | R | S | T | EOT |
|-----|---|---|---|---|---|---|---|-----|

### 5 – 2 – 1 4. [TRST] Torque peak reset

Clears the torque peak value (read by the numerical monitor command [MON:09]) stored in the servo driver.

[TRST] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | T  | R  | S  | T  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 54 | 52 | 53 | 54  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | T | R | S | T | EOT |
|-----|---|---|---|---|---|---|---|-----|

### 5 – 2 – 1 5. [PNT] Point specify

The same functionality as the control inputs P0\_IN~P7\_IN. The point number specified by this command is used in [STRON] and [TDIN] commands.

※When using this command, enable the communication command for PNT (Point number specify) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT  | Set value | Select device                  |
|----------|------|-----------|--------------------------------|
| PNT      | BIT9 | 0         | communication command<br>[PNT] |
|          | BIT8 | 1         |                                |

Example) Specify Point-Table 5 of a servo driver with axis number 3

[PNT] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | P  | N  | T  | ;  | 0  | 5  | EOT |
|              | 02  | 30 | 33 | 3B | 50 | 4E | 54 | 3B | 30 | 35 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | P | N | T | EOT |
|-----|---|---|---|---|---|---|-----|

### 5 – 2 – 1 6. [HCL] Alarm history clear

History of the past 8 alarms stored in the servo driver is cleared.

Example) Clear the alarm history of a servo driver with axis number 3

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | H  | C  | L  | EOT |
|              | 02  | 30 | 33 | 3B | 48 | 43 | 4C | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | H | C | L | EOT |
|-----|---|---|---|---|---|---|-----|

### 5 – 2 – 1 7 . [RESET] CPU reset

If the servo driver receives this command when servo is OFF, the same operation as with turning the power OFF and ON (power cycle) will be executed. (If the command is received during servo ON, [ERR:06] is returned.) To store the rewritten point data and parameters, execute [FLASH] command before [RESET] command. In addition, the machine home will be cleared, so after [RESET], perform the homing operation before use.

As the servo driver receives this command, it immediately\* resets the CPU, thus the servo driver does not reply to the controller.

\*If EEPROM writing operation is in progress when [RESET] command is received, the servo driver waits until the EEPROM writing operation is completed, and RESET operation is performed after the writing operation is completed.

Example) CPU reset of a servo driver with axis number 3

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|-----|
|              | STX | 0  | 3  | ;  | R  | E  | S  | E  | T  | EOT |
| (ASCII code) | 02  | 30 | 33 | 3B | 52 | 45 | 53 | 45 | 54 | 04  |

### 5 – 2 – 1 8 . [ZSET] Machine home rewrite

When this command is received, the machine origin is rewritten so that the specified value is the current position. (If this command is received when the position error is larger than the set value in the servo driver parameter "In-position range", [ERR:02] is returned.)

Example) Rewrite the current position to 300000 (493E0h) [pulses] in a servo driver with axis number 3

host controller ⇒ servo driver

|              |         |    |    |    |    |    |    |    |    |    |           |    |    |    |    |    |    |     |
|--------------|---------|----|----|----|----|----|----|----|----|----|-----------|----|----|----|----|----|----|-----|
|              | command |    |    |    |    |    |    |    |    |    | new value |    |    |    |    |    |    |     |
|              | STX     | 0  | 3  | ;  | Z  | S  | E  | T  | ;  | 0  | 0         | 0  | 4  | 9  | 3  | E  | 0  | EOT |
| (ASCII code) | 02      | 30 | 33 | 3B | 5A | 53 | 45 | 54 | 3B | 30 | 30        | 30 | 34 | 39 | 33 | 45 | 30 | 04  |

servo driver ⇒ host controller

|  |     |   |   |   |   |   |   |   |     |
|--|-----|---|---|---|---|---|---|---|-----|
|  | STX | 0 | 3 | ; | Z | S | E | T | EOT |
|--|-----|---|---|---|---|---|---|---|-----|

### 5 – 2 – 1 9 . [ESET] Error counter set

When this command is received, the error counter is set to the specified value (when "0" is specified, the error counter is cleared).

Example) Set the error counter to 4000 (FA0h) [pulses] in a servo driver with axis number 3

host controller ⇒ servo driver

|              |         |    |    |    |    |    |    |    |    |    |              |    |    |    |    |    |    |     |
|--------------|---------|----|----|----|----|----|----|----|----|----|--------------|----|----|----|----|----|----|-----|
|              | command |    |    |    |    |    |    |    |    |    | error pulses |    |    |    |    |    |    |     |
|              | STX     | 0  | 3  | ;  | E  | S  | E  | T  | ;  | 0  | 0            | 0  | 0  | 0  | F  | A  | 0  | EOT |
| (ASCII code) | 02      | 30 | 33 | 3B | 45 | 53 | 45 | 54 | 3B | 30 | 30           | 30 | 30 | 30 | 46 | 41 | 30 | 04  |

servo driver ⇒ host controller

|  |     |   |   |   |   |   |   |   |     |
|--|-----|---|---|---|---|---|---|---|-----|
|  | STX | 0 | 3 | ; | E | S | E | T | EOT |
|--|-----|---|---|---|---|---|---|---|-----|

## 5 – 2 – 2 0. [RSELON] [RSELOFF] Resolution selection

The same functionality as turning ON or OFF the control input signal RSEL. The command switches the resolution of reference pulse.

※When using this command, enable the communication command for RSEL (Reference pulse multiply select) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8 . Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable setting

| Function | BIT   | Set value | Select device                               |
|----------|-------|-----------|---|
| RSEL     | BIT11 | 0         | communication command<br>[RSELON] [RSELOFF] |
|          | BIT10 | 1         |   |

Example) Select resolution of a servo driver with axis number 3

## [RSELON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | R  | S  | E  | L  | O  | N  | EOT |
|              | 02  | 30 | 33 | 3B | 52 | 53 | 45 | 4C | 4F | 4E | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | R | S | E | L | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

## [RSELOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | R  | S  | E  | L  | O  | F  | F  | EOT |
|              | 02  | 30 | 33 | 3B | 52 | 53 | 45 | 4C | 4F | 46 | 46 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | R | S | E | L | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

## 5 – 2 – 2 1. [TSELON] [TSELOFF] [TSEL0ON] [TSEL1ON] [TSEL2ON] [TSEL3ON] [TSEL4ON] Torque select

The same functionality as the control inputs TSEL0~TSEL4. With this command, the torque limit value is switched to the value set in the parameters "Torque limit value select 0"~"Torque limit value select 4" of the servo driver.

With [TSELON] arguments 0~4 the torque 0~4 is selected.

[TSELOFF] command turns OFF all control input signals TSEL0~TSEL4 (torque limit is deselected).

※When using this command, enable the communication command for TSEL (Torque limit value) function by selecting the command input method.

If not enabled, a communication error [ERR:04] (Input method not selected) will be returned.

For details on command input method selection, refer to "3 – 8. Command input method select".

Parameter N0006 "Command input method select": Serial communication command enable

| Function | BIT   | Set value | Select device                                    |
|----------|-------|-----------|--|
| TSEL     | BIT13 | 0         | communication command<br>[TSELON] [TSELOFF] etc. |
|          | BIT12 | 1         |  |

Example) Select torque limit value of a servo driver with axis number 3

<Example 1> Select TSEL2 with the [TSELON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | T  | S  | E  | L  | O  | N  | ;  | 2  | EOT |
|              | 02  | 30 | 33 | 3B | 54 | 53 | 45 | 4C | 4F | 4E | 3B | 32 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | T | S | E | L | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

<Example 2> Select TSEL2 with the [TSEL2ON] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | T  | S  | E  | L  | 2  | O  | N  | EOT |
|              | 02  | 30 | 33 | 3B | 54 | 53 | 45 | 4C | 32 | 4F | 4E | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | T | S | E | L | 2 | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

[TSELOFF] command

host controller ⇒ servo driver

|              |     |    |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | T  | S  | E  | L  | O  | F  | F  | EOT |
|              | 02  | 30 | 33 | 3B | 54 | 53 | 45 | 4C | 4F | 45 | 45 | 04  |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | T | S | E | L | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 2 2. [MFINON] [MFINOFF] M complete input ON/OFF

The same functionality as turning ON/OFF the control input signal MFIN.

Example) Turn M complete ON and OFF in a servo driver with axis number 3

[MFINON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | M  | F  | I  | N  | O  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 4D | 46 | 49 | 4E | 4F | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | M | F | I | N | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

[MFINOFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | M  | F  | I  | N  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 4D | 46 | 49 | 4E | 4F | 46 | 46  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | M | F | I | N | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 2 3. [STEPON] [STEPOFF] [STEP0ON] [STEP1ON] [STEP2ON] [STEP3ON]

Step operation

Starts and stops the step operation.

With [STEPON] arguments 0~3 the step operation 0~3 is selected.

If [STEPOFF] command is received during step operation, the motor will decelerate and stop.

Example) Start and stop the step operation of a servo driver with axis number 3

<Example 1> Start step 2 operation with [STEPON] command

[STEPON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | E  | P  | O  | N  | ;  | 2  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 53 | 54 | 45 | 50 | 4F | 4E | 3B | 32  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | E | P | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|-----|

<Example 2> Start step operation 2 with the [STEP2ON] command

[STEP2ON] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | E  | P  | 2  | O  | N  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 53 | 54 | 45 | 50 | 32 | 4F | 4E  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | E | P | 2 | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

[STEPOFF] command

host controller ⇒ servo driver

|              |    |    |    |    |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | S  | T  | E  | P  | O  | F  | F  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 54 | 53 | 45 | 4C | 4F | 45 | 45  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | T | E | P | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

### 5 – 2 – 2 4. [STEP0P] [STEP0N] [STEP1P] [STEP1N] [STEP2P] [STEP2N] [STEP3P] [STEP3N] Step operation (direction specified)

Starts the step operation.

With [STEP0P] [STEP1P] [STEP2P] [STEP3P] the step operation is performed in forward direction for the absolute pulse number distance set in the parameters "Step operation pulses 0~3".

With [STEP0N] [STEP1N] [STEP2N] [STEP3N] the step operation is performed in reverse direction for the absolute pulse number distance set in the parameters "Step operation pulses 0~3".

Example) Start the step operation forward 2 of a servo driver with axis number 3

|                                |   |     |    |    |    |    |    |    |    |     |    |     |  |    |    |    |    |    |    |    |    |    |    |    |
|--------------------------------|---|-----|----|----|----|----|----|----|----|-----|----|-----|--|----|----|----|----|----|----|----|----|----|----|----|
| host controller ⇒ servo driver |   |     |    |    |    |    |    |    |    |     |    |     |  |    |    |    |    |    |    |    |    |    |    |    |
| (ASCII code)                   | <table border="1"> <tr> <td>STX</td><td>0</td><td>3</td><td>;</td><td>S</td><td>T</td><td>E</td><td>P</td><td>2</td><td>P</td><td>EOT</td> </tr> <tr> <td></td><td>02</td><td>30</td><td>33</td><td>3B</td><td>53</td><td>54</td><td>45</td><td>50</td><td>32</td><td>50</td><td>04</td> </tr> </table> | STX | 0  | 3  | ;  | S  | T  | E  | P  | 2   | P  | EOT |  | 02 | 30 | 33 | 3B | 53 | 54 | 45 | 50 | 32 | 50 | 04 |
| STX                            | 0   | 3   | ;  | S  | T  | E  | P  | 2  | P  | EOT |    |     |  |    |    |    |    |    |    |    |    |    |    |    |
|                                | 02  | 30  | 33 | 3B | 53 | 54 | 45 | 50 | 32 | 50  | 04 |     |  |    |    |    |    |    |    |    |    |    |    |    |
| servo driver ⇒ host controller |   |     |    |    |    |    |    |    |    |     |    |     |  |    |    |    |    |    |    |    |    |    |    |    |
|                                | <table border="1"> <tr> <td>STX</td><td>0</td><td>3</td><td>;</td><td>S</td><td>T</td><td>E</td><td>P</td><td>2</td><td>P</td><td>EOT</td> </tr> </table>   | STX | 0  | 3  | ;  | S  | T  | E  | P  | 2   | P  | EOT |  |    |    |    |    |    |    |    |    |    |    |    |
| STX                            | 0   | 3   | ;  | S  | T  | E  | P  | 2  | P  | EOT |    |     |  |    |    |    |    |    |    |    |    |    |    |    |

### 5 – 2 – 2 5. [SLREQON] [SLREQOFF] Transition to / Cancel sensor input standby state

The current position latch function controls transition and cancellation of the sensor input standby state.

For details on current position latch function, refer to Instruction Manual: Main part "14-3-2. Current position latch function".

Example) Transition / cancellation of sensor input standby state of a servo driver with axis number 3

#### [SLREQON] command

host controller ⇒ servo driver

|              |  |     |    |    |    |    |    |    |    |    |     |    |     |  |    |    |    |    |    |    |    |    |    |    |    |    |
|--------------|--|-----|----|----|----|----|----|----|----|----|-----|----|-----|--|----|----|----|----|----|----|----|----|----|----|----|----|
| (ASCII code) | <table border="1"> <tr> <td>STX</td><td>0</td><td>3</td><td>;</td><td>S</td><td>L</td><td>R</td><td>E</td><td>Q</td><td>O</td><td>N</td><td>EOT</td> </tr> <tr> <td></td><td>02</td><td>30</td><td>33</td><td>3B</td><td>53</td><td>4C</td><td>52</td><td>45</td><td>51</td><td>4F</td><td>4E</td><td>04</td> </tr> </table> | STX | 0  | 3  | ;  | S  | L  | R  | E  | Q  | O   | N  | EOT |  | 02 | 30 | 33 | 3B | 53 | 4C | 52 | 45 | 51 | 4F | 4E | 04 |
| STX          | 0  | 3   | ;  | S  | L  | R  | E  | Q  | O  | N  | EOT |    |     |  |    |    |    |    |    |    |    |    |    |    |    |    |
|              | 02   | 30  | 33 | 3B | 53 | 4C | 52 | 45 | 51 | 4F | 4E  | 04 |     |  |    |    |    |    |    |    |    |    |    |    |    |    |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | L | R | E | Q | O | N | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|-----|

#### [SLREQOFF] command

host controller ⇒ servo driver

|              |   |     |    |    |    |    |    |    |    |    |    |     |    |     |  |    |    |    |    |    |    |    |    |    |    |    |    |    |
|--------------|---|-----|----|----|----|----|----|----|----|----|----|-----|----|-----|--|----|----|----|----|----|----|----|----|----|----|----|----|----|
| (ASCII code) | <table border="1"> <tr> <td>STX</td><td>0</td><td>3</td><td>;</td><td>S</td><td>L</td><td>R</td><td>E</td><td>Q</td><td>O</td><td>F</td><td>F</td><td>EOT</td> </tr> <tr> <td></td><td>02</td><td>30</td><td>33</td><td>3B</td><td>53</td><td>4C</td><td>52</td><td>45</td><td>51</td><td>4F</td><td>46</td><td>46</td><td>04</td> </tr> </table> | STX | 0  | 3  | ;  | S  | L  | R  | E  | Q  | O  | F   | F  | EOT |  | 02 | 30 | 33 | 3B | 53 | 4C | 52 | 45 | 51 | 4F | 46 | 46 | 04 |
| STX          | 0   | 3   | ;  | S  | L  | R  | E  | Q  | O  | F  | F  | EOT |    |     |  |    |    |    |    |    |    |    |    |    |    |    |    |    |
|              | 02  | 30  | 33 | 3B | 53 | 4C | 52 | 45 | 51 | 4F | 46 | 46  | 04 |     |  |    |    |    |    |    |    |    |    |    |    |    |    |    |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | S | L | R | E | Q | O | F | F | EOT |
|-----|---|---|---|---|---|---|---|---|---|---|---|-----|

## 5 - 2 - 2 6 . [DPS] Direct positioning start

Specify the positioning profile data and start operation.

For details on positioning operation, refer to Instruction Manual: Main part "14-3-1. Profile operation command" .

The content of the positioning profile data id as follows.

| Item                           | Explanation  | Unit                         |
|--------------------------------|--|------------------------------|
| Absolute value target position | Specify the final target position (absolute value) for positioning.  | Reference unit               |
| Target velocity                | Specify the target velocity for positioning operation in [min <sup>-1</sup> ].   | min <sup>-1</sup>            |
| Acceleration time constant     | Set the acceleration time from velocity 0 to 3000min <sup>-1</sup> in [ms].<br>※If deceleration time constant is omitted, this data will be applied to both acceleration and deceleration. | ms/<br>3000min <sup>-1</sup> |
| Deceleration time constant     | Set the acceleration time from velocity 3000 to min <sup>-1</sup> in [ms].<br>※This data can be omitted.<br>If omitted, deceleration operates at the same slope as acceleration.           | ms/<br>3000min <sup>-1</sup> |

Example) Start positioning of a Si3 servo with axis number 3

host controller ⇒ Si3 servo driver

|              |  | Command         |    |    |    |                   |    |    | Absolute value target position |                   |    |    |    |    |    |     |    |    |
|--------------|--|-----------------|----|----|----|-------------------|----|----|--------------------------------|-------------------|----|----|----|----|----|-----|----|----|
| (ASCII code) |  | STX             | 0  | 3  | ;  | D                 | P  | S  | ;                              | 0                 | 0  | 0  | 3  | 0  | D  | 4   | 0  | ;  |
|              |  | 02              | 30 | 33 | 3B | 44                | 50 | 53 | 3B                             | 30                | 30 | 30 | 33 | 30 | 44 | 34  | 30 | 3B |
|              |  | Target velocity |    |    |    | Acc time constant |    |    |                                | Dec time constant |    |    |    |    |    |     |    |    |
|              |  | 0               | 7  | D  | 0  | ;                 | 0  | 1  | F                              | 4                 | ;  | 0  | 3  | E  | 8  | EOT |    |    |
|              |  | 30              | 37 | 44 | 30 | 3B                | 30 | 31 | 46                             | 34                | 3B | 30 | 33 | 45 | 38 | 04  |    |    |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | D | P | S | EOT |
|-----|---|---|---|---|---|---|-----|

## 5 – 3. Monitor commands

### 5 – 3 – 1. [MON] Value monitor

Reads various numerical values.

Example) Read the command remain distance of a servo driver with axis number 3  
(the read value is 16550 (40A6h) pulses)

host controller ⇒ servo driver      monitor number [hexadecimal 2 characters]

|              |     |    |    |    |    |    |    |    |    |    |     |
|--------------|-----|----|----|----|----|----|----|----|----|----|-----|
| (ASCII code) | STX | 0  | 3  | ;  | M  | O  | N  | ;  | 0  | 3  | EOT |
|              | 02  | 30 | 33 | 3B | 4D | 4F | 4E | 3B | 30 | 33 | 04  |

servo driver ⇒ host controller      monitor number [hexadecimal 2 characters]

|     |   |   |   |   |   |   |   |   |   |
|-----|---|---|---|---|---|---|---|---|---|
| STX | 0 | 3 | ; | M | O | N | ; | 0 | 3 |
|-----|---|---|---|---|---|---|---|---|---|

|   |   |   |   |   |   |   |   |   |     |
|---|---|---|---|---|---|---|---|---|-----|
| ; | 0 | 0 | 0 | 0 | 4 | 0 | A | 6 | EOT |
|---|---|---|---|---|---|---|---|---|-----|

The values read for each monitor number are shown in the table below

| Number | Name  | Content  |
|--------|---|--|
| 00     | Actual position                                     | Returns the current motor position (feedback pulses) in reference units.   |
| 01     | Reference position                                  | Returns the current reference position in reference units.   |
| 02     | Position error                                      | Returns the current position error in motor encoder pulse units.   |
| 03     | Command remain distance                             | Returns the remaining move amount for Point-Table positioning in reference units. Returns 0 except during the point positioning.                                     |
| 04     | Actual velocity                                     | The current velocity (calculated from feedback pulses) is returned in [min <sup>-1</sup> ] units.  |
| 05     | Velocity of reference position                      | Returns the current velocity of reference position in [min <sup>-1</sup> ].  |
| 06     | Actual Torque                                       | Returns current torque as a percentage of rated torque (ratio of detected current to rated current). (with sign)   |
| 07     | Relative command value                              | Returns the command amount calculated from the start of point positioning.   |
| 08     | Sensor position (for compatibility with old models) | The distance from the sensor startup to the current position is returned in the case of sensor positioning.  |
| 09     | Torque peak   | Returns the peak torque as a percentage of the rated torque (absolute value). Returns the maximum value of "Actual Torque" item.                                     |
| 0A     | Executing point table No.                           | Returns the currently executed point table number.   |
| 0C     | DEC-Z distance                                      | Returns the distance between home deceleration LS and Z pulse in motor encoder pulse units. This value is updated when Z pulse is detected in returning to home.     |
| 0E     | Communication command status                        | Returns the status of soft switches set by the communication command. Each bit's value 1 indicates the ON state. See the table below for correspondence of each bit. |
| 10     | Servo status  | Returns the servo status as bits. See the table below for correspondence of each bit.  |
| 13     | Completed point number                              | Returns the execution completed point number.  |
| 14     | Z pulse latch position                              | Returns the position when the Z pulse signal rises.  |
| 15     | Sensor latch position                               | Returns the position when the SENS signal rises.   |
| 16     | Torque output effective value                       | Returns the torque output effective value (root mean square). Indicates the degree of variation in load torque.  |
| 17     | Velocity error effective value                      | Returns the velocity error effective value (root mean square). Indicates the degree of variation in motor rotation speed.  |

MON;0E [Communication command status] BIT correspondence table

| BIT | Communication command status | BIT | Communication command status |
|-----|------------------------------|-----|------------------------------|
| 31  | —                            | 15  | TSEL3                        |
| 30  | —                            | 14  | TSEL2                        |
| 29  | —                            | 13  | TSEL1                        |
| 28  | —                            | 12  | TSEL0                        |
| 27  | —                            | 11  | EXIN3                        |
| 26  | —                            | 10  | EXIN2                        |
| 25  | —                            | 09  | EXIN                         |
| 24  | —                            | 08  | SBK                          |
| 23  | —                            | 07  | HOLD                         |
| 22  | —                            | 06  | DEC                          |
| 21  | TSTR                         | 05  | ZSTR                         |
| 20  | SLREQ                        | 04  | STR                          |
| 19  | MFIN                         | 03  | EMC (servo free)             |
| 18  | RSEL                         | 02  | NJOG                         |
| 17  | EMCE (control braking)       | 01  | PJOG                         |
| 16  | TSEL4                        | 00  | SVON                         |

MON;10 [Servo status] BIT correspondence table

| BIT | Servo status     | BIT | Servo status                      |
|-----|------------------|-----|-----------------------------------|
| 31  | Servo ON         | 15  | RUN                               |
| 30  | -OT              | 14  | —                                 |
| 29  | —                | 13  | —                                 |
| 28  | —                | 12  | Sensor detection completed (SFIN) |
| 27  | EMC              | 11  | Homing completed (ZFIN)           |
| 26  | —                | 10  | —                                 |
| 25  | —                | 09  | —                                 |
| 24  | +OT              | 08  | COIN (FIN)                        |
| 23  | Alarm            | 07  | —                                 |
| 22  | Velocity limiter | 06  | BB (base block)                   |
| 21  | —                | 05  | —                                 |
| 20  | —                | 04  | —                                 |
| 19  | Torque limiter   | 03  | In point operation                |
| 18  | —                | 02  | —                                 |
| 17  | —                | 01  | —                                 |
| 16  | Excessive error  | 00  | —                                 |

### 5 – 3 – 2 . [ALM] Alarm information

The current alarm status and the history of past 8 alarms are returned as "Alarm category numbers". BITs corresponding to the occurred alarm category are set in the reply data. For details about the alarm category codes refer to Si servo3 Instruction manual (Main part).

Use [ALMP] and [ALMHP] to read the detailed alarm code in the alarm category.

Correspondence between alarm numbers, alarm category numbers, and BITs is shown in the table below.

| BIT  | Number (※) | BIT   | Number (※) |
|------|------------|-------|------------|
| BIT0 | 01         | BIT8  | 09         |
| BIT1 | 02         | BIT9  | 10         |
| BIT2 | 03         | BIT10 | 11         |
| BIT3 | 04         | BIT11 | 12         |
| BIT4 | 05         | BIT12 | 13         |
| BIT5 | 06         | BIT13 | 14         |
| BIT6 | 07         | BIT14 | 15         |
| BIT7 | 08         | BIT15 | -          |

※Si servo2: Alarm number

Si servo3: Alarm category number

Example) Read the alarm information of a servo driver with axis number 3 (detect BIT5 and BIT6)

host controller ⇒ servo driver

|              |  | Command |    |    |    |    |    |    |     |
|--------------|--|---------|----|----|----|----|----|----|-----|
| (ASCII code) |  | STX     | 0  | 3  | ;  | A  | L  | M  | EOT |
|              |  | 02      | 30 | 33 | 3B | 41 | 4C | 4D | 04  |

servo driver ⇒ host controller      alarm occurrence status [hexadecimal 4 characters]

|                 |   |   |   |   |   |   |   |     |   |   |   |
|-----------------|---|---|---|---|---|---|---|-----|---|---|---|
| STX             | 0 | 3 | ; | A | L | M | ; | 0   | 0 | 6 | 0 |
| Alarm history 1 |   |   |   |   |   |   |   |     |   |   |   |
|                 |   | ; |   | 0 | 0 | 4 | 0 |     |   |   |   |
| Alarm history 2 |   |   |   |   |   |   |   |     |   |   |   |
|                 |   | ; |   | 0 | 0 | 2 | 0 |     |   |   |   |
| :               |   |   |   |   |   |   |   |     |   |   |   |
| Alarm history 8 |   |   |   |   |   |   |   |     |   |   |   |
|                 |   | ; |   | 0 | 0 | 0 | 1 | EOT |   |   |   |

## 5 – 3 – 3. [IO2] I/O monitor 2

Monitors the status of control input/output terminals. In the reply data, the upper 16 BITs represent the status of input terminals, and the lower 16 BITs represent the status of output terminals, where BIT value 1 corresponds to a closed state of the terminal.

| Input |        | Output |             |
|-------|--------|--------|-------------|
| BIT   | Device | BIT    | Device      |
| 31    | —      | 15     | —           |
| 30    | —      | 14     | —           |
| 29    | —      | 13     | —           |
| 28    | —      | 12     | —           |
| 27    | —      | 11     | —           |
| 26    | —      | 10     | —           |
| 25    | —      | 09     | —           |
| 24    | —      | 08     | —           |
| 23    | —      | 07     | —           |
| 22    | —      | 06     | —           |
| 21    | —      | 05     | LED (red)   |
| 20    | IN4    | 04     | LED (green) |
| 19    | IN3    | 03     | BK          |
| 18    | IN2    | 02     | OUT2        |
| 17    | IN1    | 01     | OUT1        |
| 16    | IN0    | 00     | OUT0        |

Example) Read I/O status of a servo driver with axis number 3  
host controller ⇒ servo driver

|              |    |    |    |    |    |    |     |    |
|--------------|----|----|----|----|----|----|-----|----|
| STX          | 0  | 3  | ;  | I  | O  | 2  | EOT |    |
| (ASCII code) | 02 | 30 | 33 | 3B | 49 | 4F | 32  | 04 |

servo driver ⇒ host controller

|     |   |   |   |   |   |   |   |                 |   |   |   |                  |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----------------|---|---|---|------------------|---|---|---|-----|
| STX | 0 | 3 | ; | I | O | 2 | ; | 0               | 5 | 9 | 1 | 0                | 0 | 3 | 9 | EOT |
|     |   |   |   |   |   |   |   | input terminals |   |   |   | output terminals |   |   |   |     |

## 5-3-4. [ALMP] Alarm read

Read the currently occurring alarm list (16) in batch.

host controller ⇒ servo driver

Axis number

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | A | L | M | P | EOT |
|-----|---|---|---|---|---|---|---|-----|

servo driver ⇒ host controller

axis number      occurring alarm 1      occurring alarm 2

|     |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
|-----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| STX | 0 | 3 | ; | A | L | M | P | ; | 0 | 0 | 0 | 0 | ; | 0 | 0 | 0 | 0 | ; |
|-----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

occurring alarm 3      (omitted: 4~14)      occurring alarm 15      occurring alarm 16

|   |   |   |   |   |  |   |   |   |   |   |   |   |   |   |   |     |
|---|---|---|---|---|--|---|---|---|---|---|---|---|---|---|---|-----|
| 0 | 0 | 0 | 0 | ; |  | ; | 0 | 0 | 0 | 0 | ; | 0 | 0 | 0 | 0 | EOT |
|---|---|---|---|---|--|---|---|---|---|---|---|---|---|---|---|-----|

## 5-3-5. [ALHP] Alarm history read

Read the alarm history (31) in batch.

host controller ⇒ servo driver

Axis number

|     |   |   |   |   |   |   |   |     |
|-----|---|---|---|---|---|---|---|-----|
| STX | 0 | 3 | ; | A | L | H | P | EOT |
|-----|---|---|---|---|---|---|---|-----|

servo driver ⇒ host controller

axis number      alarm history 1      alarm history 2

|     |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
|-----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| STX | 0 | 3 | ; | A | L | H | P | ; | 0 | 0 | 0 | 0 | ; | 0 | 0 | 0 | 0 | ; |
|-----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

alarm history 3      (omitted: 4~29)      alarm history 30      alarm history 31

|   |   |   |   |   |  |   |   |   |   |   |   |   |   |   |   |     |
|---|---|---|---|---|--|---|---|---|---|---|---|---|---|---|---|-----|
| 0 | 0 | 0 | 0 | ; |  | ; | 0 | 0 | 0 | 0 | ; | 0 | 0 | 0 | 0 | EOT |
|---|---|---|---|---|--|---|---|---|---|---|---|---|---|---|---|-----|

The alarm history 1 is the latest (last generated).

### 5 – 3 – 6 . [DIAG] Monitor·Read diagnostic information

Reads various numerical values and bit data indicating the operating status of Si servo3 driver.

Specify the diagnostic information number (0~31) and the monitor number (0~255) in the data.

Specify 0 as the diagnostic information number to read the current diagnostic information, and 1~31 to read the diagnostic information when a past alarm occurred. The latest diagnostic information (when the last alarm occurred) is information No.1.

For details on the monitor number, refer to the Monitor data and diagnostic information in the Si servo3 Instruction manual (Main part).

Example) Read the command remain distance (monitor number 100) at the time of the last alarm in a servo driver with axis number 3

host controller ⇒ servo driver

|     | axis number |   |   |   | diagnostic number |   |   |   | monitor number |   |   |   |   |   |     |
|-----|-------------|---|---|---|-------------------|---|---|---|----------------|---|---|---|---|---|-----|
| STX | 0           | 3 | ; | D | I                 | A | G | ; | 0              | 1 | ; | 0 | 6 | 4 | EOT |

servo driver ⇒ host controller

|     | axis number |   |   |   | monitor data |   |   |   |   |   |   |   |   |   |   |   |     |
|-----|-------------|---|---|---|--------------|---|---|---|---|---|---|---|---|---|---|---|-----|
| STX | 0           | 3 | ; | D | I            | A | G | ; | 0 | 0 | 0 | 0 | 4 | 0 | A | 6 | EOT |

## 6. Appendix

## 6 – 1. Old model (Si servo2) parameters correspondence table

| Si2 No. | Si2 parameter name                             | Si3 No. | Si3 parameter name                                 | Remarks  |
|---------|--|---------|--|--|
| 0       | Axis number                                    | N0020   | Axis number  |  |
| 1       | Control input function preset setting          | -       | -  |  |
| 2       | Resolution numerator                           | N0003   | Electronic gear denominator                        | Resolution numerator = Electronic gear denominator         |
| 3       | Resolution denominator                         | N0002   | Electronic gear numerator                          | Resolution denominator x 10000 = Electronic gear numerator |
| 4       | Pulse command multiply                         | N0401   | Reference pulse multiply 2                         | N0400: Reference pulse multiply 1 is "1"                   |
| 5       | -  | -       | -  |  |
| 6       | Forward software OT                            | N0004   | Forward direction software OT                      |  |
| 7       | Reverse software OT                            | N0005   | Reverse direction software OT                      |  |
| 8       | Current down current                           | N0125   | Current down current                               |  |
| 9       | Current down time limit                        | N0126   | Current down time limit                            |  |
| 10      | Preset servo gain select                       | -       | -  |  |
| 11      | Position proportional gain                     | N0101   | Position proportional gain                         |  |
| 12      | Position feedforward coefficient               | N0105   | Velocity feedforward coefficient                   |  |
| 13      | Velocity proportional gain                     | N0104   | Load moment of inertia                             |  |
| 14      | Velocity derivative gain                       | -       | -  |  |
| 15      | Velocity integral gain                         | -       | -  |  |
| 16      | Integral operation in holding state            | -       | -  |  |
| 17      | Maximum position error                         | N0412   | Maximum position error                             |  |
| 18      | In-position range                              | N0000   | In-position range                                  |  |
| 19      | Torque completed/<br>VZR output range          | N0207   | Torque completed/<br>VZR output range              |  |
| 20      | Input pulse type                               | N0007   | Reference pulse type select                        |  |
| 21      | Jog velocity                                   | N0310   | Jog velocity                                       |  |
| 22      | Jog acc/dec time constant                      | N0311   | Jog acc/dec time constant                          |  |
| 23      | Step operation pulses 0                        | N0312   | Step operation pulses 0                            |  |
| 24      | Step operation pulses 1                        | N0313   | Step operation pulses 1                            |  |
| 25      | Step operation pulses 2                        | N0314   | Step operation pulses 2                            |  |
| 26      | Step operation pulses 3                        | N0315   | Step operation pulses 3                            |  |
| 27      | Homing method                                  | N0300   | Homing method select                               |  |
| 28      | Homing direction                               | N0301   | Homing direction select                            |  |
| 29      | Homing fast velocity                           | N0302   | Homing approach velocity                           |  |
| 30      | Homing slow velocity                           | N0303   | Homing creep velocity                              |  |
| 31      | Homing acc/dec time constant                   | N0304   | Homing acc/dec time constant                       |  |
| 32      | Homing final travel distance                   | N0305   | Homing final travel distance                       |  |
| 33      | Homing push torque                             | N0306   | Homing push torque                                 | Si2:[%]units↔Si3:[0.1%]units conversion                    |
| 34      | Velocity limit during torque limit             | N0210   | Velocity limit during torque limit                 |  |
| 35      | Velocity limit when torque limit is released   | N0211   | Velocity limit when torque limit is released       |  |
| 36      | Velocity limit acc/dec time constant           | N0212   | Velocity limit acc/dec time constant               |  |
| 37      | Torque limit inc/dec time constant             | N0208   | Torque limit inc/dec time constant                 |  |
| 38      | Operation mode switch                          | N0019   | Velocity control operation mode select             |  |
| 39      | Alarm output time constant                     | N0406   | Alarm signal output time constant                  |  |
| 40      | Z phase output time                            | N0407   | ZPLS output minimum time/<br>Stop time agter PTFIN |  |
| 41      | Control input filter time constant             | N0408   | Control input filter time constant                 |  |
| 42      | Reference pulse smoothing filter time constant | N0402   | Reference pulse smoothing filter time constant     |  |
| 43      | Communication format select                    | N0419   | Communication format select                        |  |
| 44      | Reply wait time                                | N0420   | Reply wait time                                    |  |
| 45      | Input method select                            | N0006   | Command input method select                        |  |
| 46      | -  | -       | -  |  |

| Si2 No. | Si2 parameter name                             | Si3 No. | Si3 parameter name                            | Remarks  |
|---------|--|---------|---|--|
| 47      | Servo free delay time                          | N0411   | Servo free delay time                         |  |
| 48      | Rotation direction select                      | N0001   | Motor rotation direction select               |  |
| 49      | Motor power voltage                            | -       | -   |  |
| 50      | Open loop maximum velocity                     | -       | -   |  |
| 51      | Open loop maximum position error               | -       | -   |  |
| 52      | In-position output permission sampling time    | N0405   | In-position output permission time            |  |
| 53      | Startup excitation hold time                   | N0421   | Startup excitation hold time                  |  |
| 54      | Point selection multiply                       | N0416   | Point selection multiply                      |  |
| 55      | VCMP output range                              | N0414   | VCMP output range                             |  |
| 56      | Auto tuning                                    | -       | -   |  |
| 57      | Number of pulses in rotating coordinate system | N0418   | Rotating coordinate system upper limit        | N0417: Rotating coordinate system lower limit is "0" |
| 58      | Machine edge detect sequence                   | N0422   | Initial coordinate detection operation select |  |
| 59      | Number of grid mask pulses                     | N0307   | Homing grid mask pulses                       |  |
| 60      | Extended input set 1                           | N0008   | Control input function select: IN0            | parameter 60 BIT0~BIT7 ⇔ N0008                       |
|         |  | N0009   | Control input function select: IN1            | parameter 60 BIT8~BIT15 ⇔ N0009                      |
|         |  | N0010   | Control input function select: IN2            | parameter 60 BIT16~BIT23 ⇔ N0010                     |
|         |  | N0011   | Control input function select: IN3            | parameter 60 BIT24~BIT31 ⇔ N0011                     |
| 61      | Extended input set 2                           | N0012   | Control input function select: IN4            |  |
| 62      | -  | -       | -   |  |
| 63      | Extended output set                            | N0013   | Control output function select: OUT0          | parameter 63 BIT0~BIT7 ⇔ N0013                       |
|         |  | N0014   | Control output function select: OUT1          | parameter 63 BIT8~BIT15 ⇔ N0014                      |
|         |  | N0015   | Control output function select: OUT2          | parameter 63 BIT16~BIT23 ⇔ N0015                     |
| 64      | -  | -       | -   |  |
| 65      | Control input logic set                        | N0017   | Control input logic selection                 |  |
| 66      | Control output logic set                       | N0018   | Control output logic selection                |  |
| 67      | -  | -       | -   |  |
| 68      | Alarm output protection set                    | N0413   | Alarm output protection set                   |  |
| 69      | -  | -       | -   |  |
| 70      | Torque select 0                                | N0202   | Torque limit value select 0                   | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 71      | Torque select 1                                | N0203   | Torque limit value select 1                   | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 72      | Torque select 2                                | N0204   | Torque limit value select 2                   | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 73      | Torque select 3                                | N0205   | Torque limit value select 3                   | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 74      | Torque select 4                                | N0206   | Torque limit value select 4                   | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 75      | Forward torque limiter                         | N0200   | Forward direction basic torque limit          | Si2:[%]units⇔Si3:[0.1%]units conversion              |
| 76      | Reverse torque limiter                         | N0201   | Reverse direction basic torque limit          | Si2:[%]units⇔Si3:[0.1%]units conversion              |

---



---

 ■Contact information■■■

(Sales inquiry)

Sanmei Co., Ltd.

E-mail : [service@sanmei.co.jp](mailto:service@sanmei.co.jp)

|   |           |  |
|---|-----------|--|
| H e a d o f f i c e                             | 〒424-0825 | 6-16 Matsubara-cho, Shimizu-ku, Shizuoka-shi, Shizuoka<br>TEL (054)353-3271 FAX (054)352-1648                              |
| T o k y o b r a n c h                           | 〒113-0033 | Hongo Core Building 3F<br>3-43-16 Hongo, Bunkyo-ku, Tokyo<br>TEL (03)5803-1621 FAX (03)3813-3431                           |
| North Kanto sales office                        | 〒360-0041 | Miyamachi City Hall Building 3F<br>2-138 Miyamachi, Kumagaya-shi, Saitama<br>TEL (048)527-0780 FAX (048)527-1340           |
| Yamagata sales office                           | 〒990-0023 | Habitation II 102<br>1-15-31 Matsunami, Yamagata-shi, Yamagata<br>TEL (023)629-6455 FAX (023)629-6456                      |
| West Tokyo branch<br>Kanagawa sales office      | 〒243-0035 | Yasudaya Building 3F<br>1-4-3 Aiko, Atsugi-shi, Kanagawa<br>TEL (046)280-6230 FAX (046)280-6237                            |
| Numazu sales office                             | 〒410-0062 | 14-4 Miyamaemachi, Numazu-shi, Shizuoka<br>TEL (055)922-5333 FAX (055)922-3609   |
| C h u b u b r a n c h<br>Hamamatsu sales office | 〒430-0911 | 658-1, Niitsu-cho, Naka-ku, Hamamatsu-shi, Shizuoka<br>TEL (053)461-1094 FAX (053)461-3879                                 |
| Nagoya sales office                             | 〒464-0075 | Imaike Central Building 6F B-2<br>3-10-17 Uchiyama, Chikusa-ku, Nagoya-shi, Aichi<br>TEL (052)753-5605 FAX (052)753-5603   |
| O s a k a b r a n c h                           | 〒532-0011 | Third Nakajima Building 10F<br>5-11-10 Nishinakajima, Yodogawa-ku, Osaka-shi, Osaka<br>TEL (06)6309-5123 FAX (06)6305-0326 |
| Hokuriku sales office                           | 〒930-0966 | Hirota Building 1F<br>2-4-2 Ishigane, Toyama-shi, Toyama<br>TEL (076)420-6573 FAX (076)420-6574                            |
| Nagano sales office                             | 〒399-8204 | 2287-28 Takaya, Toyoshina, Azumino-shi, Nagano<br>TEL (0263)71-4560 FAX (0263)71-4522                                      |
| Hachinohe sales office                          | 〒031-0822 | Hachinohe Marine Hall 3F<br>95 Mishimashita, Shirogane-machi, Hachinohe-shi, Aomori<br>TEL (0178)31-4170 FAX (0178)31-4180 |

(Technical inquiry)

Sanmei Electronics Co., Ltd.

Address: 2-2-1 Seikai, Shimizu-ku, Shizuoka-shi, Shizuoka 424-0924

TEL: (054)335-5588 FAX: (054)335-7363

E-Mail: [si-cuty@sanmei-ele.co.jp](mailto:si-cuty@sanmei-ele.co.jp)URL: <http://www.sanmei-ele.co.jp>

The content of this document is subject to change for improvement without notice.