

Q&A


Question: Is there any reason, we feel a little bit heavy, when Ball Screw starts to move?

It must be a starting Torque.

Like friction coefficient differs between Dynamic and Static, Preload Dynamic Drag Torque also differs from starting Torque.

It is well known that starting Torque is a little bit larger than Preload Dynamic Drag Torque.

One of the example is shown below.



Starting Torque is a little bit larger than normal!!!